

Universal Interface UI 710




Instruction Manual

Universal Interface UI 710

The UI 710 allows you to connect a standard telephone, the handset of the telephone and a headset of the Sennheiser Office or Call Center series.

With the UI 710, you can then switch between the headset and the handset.



Connecting the handset to the UI 710

- ▶ Pull the Western plug of the handset cable out of the telephone and connect it to the **HANDSET** socket on the UI 710 until it locks into place. An audible "click" should be heard.

Connecting the UI 710 to the telephone

- ▶ Connect the Western plug of the connecting cable to the now unoccupied handset socket on the telephone until it locks into place. An audible “click” should be heard.

Connecting the headset to the UI 710

To connect the headset, you require a telephone-specific adapter cable (accessory) which is available from your specialist dealer.

- ▶ Connect the Western plug of the adapter cable to the **HEADSET** socket on the UI 710 until it locks into place. An audible “click” should be heard.

Switching between the headset and the handset

- ▶ Press button ① to switch between the headset and the handset.
Button down: headset is activated
Button up: handset is activated

The functions of your telephone

Even with the UI 710 connected, you can use all functions of your telephone as usual. To make a call, lift the handset and dial a phone number. To end a call, replace the handset. The “hands-free conversation” function can also be used as usual.

Manufacturer declarations

Warranty

Sennheiser Communications A/S gives a warranty of 24 months on this product. For the current warranty conditions, please visit our website at www.sennheiser.com or contact your Sennheiser partner.

Australian warranty

Sennheiser's goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

This warranty is in addition to other rights or remedies under law. Nothing in this warranty excludes, limits or modifies any liability of Sennheiser which is imposed by law, or limits or modifies any remedy available to the consumer which is granted by law.

To make a claim under this warranty, contact
Sennheiser Australia Pty Ltd, Unit 3,
31 Gibbes Street Chatswood NSW 2067, AUSTRALIA
Phone: (02) 9910 6700, email: service@sennheiser.com.au.

All expenses of claiming the warranty will be borne by the person making the claim.

The Sennheiser International Warranty is provided by Sennheiser Australia Pty Ltd (ABN 68 165 388 312), Unit 3, 31 Gibbes Street Chatswood NSW 2067 Australia.

In compliance with the following requirements

WEEE Declaration (2012/19/EU)



Please dispose of this product at the end of its operational lifetime by taking it to your local collection point or recycling center for such equipment.



Batteries or rechargeable batteries



The supplied standard batteries can be recycled. Please dispose of them as special waste or return them to your specialist dealer. In order to protect the environment, only dispose of exhausted batteries.

Approval



Sennheiser electronic GmbH & Co. KG declare that this device is in compliance with the applicable CE standards and regulations.

CE Conformity

- EMC Directive (2014/30/EU)
- RoHS Directive (2011/65/EU)

The declaration is available at www.sennheiser.com.

**Before putting the product into operation,
please observe the respective country-specific regulations!**



Sennheiser Communications A/S

Industriparken 27, DK-2750 Ballerup, Denmark
www.sennheiser.com

Printed in China, Publ. 05/14, A06